

Pawprint Deluxe Grooming Stool

Assembly Instructions

Metal Seat Platform (1)

G Round Seat Cushion (1)

Backrest Arm (1)

Parts List:

Casters (5)
Five-Legged Base (1)
Foot Rest (1)
Gas Lift Mechanism (1)
Telescoping Gas Lift Cover (3 pieces)

Hardware:

Large Knob Bolt for arm (1) Large Knob Bolt for backrest (1) Hex Bolts (6) Spring Washers (4) Big Spring Washer (1) Flat Washers (4) Big Flat Washer (1) Hex Wrench (1)

Assembly instructions:

- 1. Insert all five casters into base.
- 2. Place foot rest over center of base.
- 3. Place gas lift into center of base & press firmly into base. Feed plastic telescoping pieces over gas lift.
- 4. Using hex bolts, big flat washer and big spring washer, attach metal seat mechanism to underside of cushion so that 'front' stickers are aligned. Tighten with hex wrench.
- 5. Place round seat cushion on top of gas lift mechanism. Press firmly into place.
- 6. Using the large knob for the bolt arm, a flat washer, and a spring washer, attach the backrest arm to the underside of the seat mechanism.
- 7. Feed backrest arm cover over backrest arm. Using hexbolts, attach metal backrest piece.
- 8. Place backrest over backrest arm. Tighten large bolt. Screw in large knob bolt for backrest.

© Tops Pet Products Reorder # TP1537

• Backrest Arm Cover (1) • Backrest Cushion (1) Metal Backrest Piece (1) \mathbf{K} (\mathbf{J}) -0 (\mathbf{H}) (\mathbf{G}) (\mathbf{F}) (\mathbf{I}) Ē \mathbf{D} (\mathbf{C}) **B**