

Roadster II Stroller

Instructions:



1. Unfold Stroller Frame until locking hinge on the side of the frame clicks into place.



2. Attach back wheel Assembly to back of Stroller Frame and push down until assembly locks into place.



3. Attach the Front Swivel Wheel Assembly to the front leg of the frame. Push down until locking Pin snaps into place.



4. Attach fabric panel to the bottom of stroller using Velcro® flaps.



5. Attach the Velcro® flaps on the sides of the stroller body to the belly bar of the frame.



6. Fully assembled Stroller.

Warning:

Brakes should be pushed up to the highest position before use. To lock brakes, push down on levers to the lowest position.

Folding and Storage Instructions:

1. To fold Roadster II Stroller for storage or transport, fold down Canopy, then pull up top half of plastic hinge on sides of frame to release and fold frame.
2. To secure the stroller in a folded position, loop the red plastic hook over the corresponding metal post.