





TP2533 03 • Master Equipment™ Replacement Fuse for FlashDry Dryers Replacement Instructions


Tools Required (Not Included):
Phillips-Head Screwdriver




1. Using a Phillips-head screwdriver, loosen the screws on the front panel of the dryer. Gently remove the front panel from the main body of the dryer.




2. Locate the small black cylinder inside the main body of the dryer—this is the fuse housing.



3. Unscrew the top of the fuse housing and remove the old fuse.



4. Install the new fuse and screw the two pieces of the fuse housing together to close.



5. With the screw holes on the front panel and main body of the dryer aligned, replace the front panel. Insert screws into screw holes and use a Phillips-head screwdriver to tighten all four, securing the front panel in place.