



Parts List

- (A) Dryer
- (B) Hooks for mounting
- (C) Nuts and bolts
- (D) Safety belt



1). Screw the hooks onto each of the ends of the air outlet with the open edge of the hooks facing down as shown in the photo above.

2). Use the hooks to mount the dryer on the door of the cage and clip the safety belt on the door to avoid possible drop.



3). Connect the electrical plug into a power outlet, and rotate the timer knob to "on" to power on the machine. Rotate the wind speed knob to adjust the wind speed. Rotate the timer knob to set the time at 20/ 40/ 60/ 80/ 100/ 120 minutes.

4). Turn the wind speed knob back to minimum, turn timer knob back to "Off" to turn off the machine.

CARE INSTRUCTIONS

1. Unplug the machine, and leave it until it cools down.
2. Keep the surface clean and dry, and use a soft cloth or a vacuum cleaner to clean the surface. Do not use a cleaning machine with high pressure, high temperature or liquid to clean the machine. Keep the fan blades unhurt during cleaning. Do not put the machine on a place higher than 0.5 meter.

SAFETY WARNING

1. Pet dryer requires a single outlet which meets the requirements and has ground wire. Use a dedicated extension cord and do not share with other appliances.
2. To avoid electric shock, the power outlet box should be equipped with a leakage protector.
3. Use a 3-prong extension cable with at least 1 square millimeter section area.
4. Turn Air Speed to lowest setting before tuning dryer on or off. Doing this can extend the life of the motor.
5. Do not insert pins or any metal object into the dryer to avoid electric shock or short circuit.
6. Do not use a cloth or bag to restrict the air, doing so will do damage to the dryer.
7. Do not disassemble by yourself. If the dryer has been used for some time and a malfunction occurs, you must seek professional repair service.
8. Do not leave the dryer unattended when in use.
9. Keep away from children. Children should be supervised to ensure that they do not play with the dryer.
10. The dryer is not intended for use by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the dryer by a person responsible for their safety.
11. Individuals with cardiovascular diseases or people with a pacemaker are forbidden to use this machine.
12. Keep dryer away from combustibles or explosives.
13. Unplug the dryer before repair. Turn off the dryer before unplugging.
14. Do not use dryer outdoors.
15. Do not use the product near water or in a wet or damp place. Keep away from the wet places such as the bathtub, the sink, and anything else related with water. Do not touch the machine with a wet hand.
16. Keep the dryer away from the hair, loose clothes, finger or any part of human body.
17. Keep the dryer on an even and stable surface.
18. Do not use the dryer in the cold circumstance. Do not move the dryer when it is running.
19. Do not close the door above the cord. Keep cord away from sharp edges or corners.
20. Keep the cord and plug away from the heated surface.
21. Hold the plug to disconnect it from the socket. Do not pull the cord to move the machine or use the cord as a handle.
22. If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

LIMITED WARRANTY

This Master Equipment® ProDri™ System Mini Cage Dryer is warranted against defective material or workmanship for one year from the date of purchase. Any Master Equipment® product that is determined to be defective in material or workmanship during the warranty period will be replaced without cost to the purchaser for parts or labor. Please contact Boss Pet Products Customer Service at 1-800-638-5754 regarding any defective product. Boss Pet Products will not be liable under this warranty for any defect, failure or malfunction of this product caused by normal wear, abuse, misuse, unauthorized adjustments or repairs. Boss Pet Products will not be liable for any incidental or consequential damages of any type. Any implied warranty is limited to the one-year period provided in this express warranty. Some states do not allow limitations on how long an implied warranty lasts or exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. Warranty is void if product has been modified in any manner, repaired by anyone other than Boss Pet Products or has been subject to unreasonable use. Warranty is valid in the United States.

Date Purchase: _____



Manufactured for
© Boss Pet Products, Inc., Danvers, MA 01923
MADE IN CHINA

TP9033 99 Master Equipment®
ProDri™ System Mini Cage Dryer