
Basic Controls

Turn on the power switch before use

Wind speed & Temperature adjustment are controlled by precision adjustable resistance switches turn clockwise for higher, counterclockwise to lower. Notice: do not force dials beyond range to avoid damaging the switch knob.

Notice: After continuous use for a long time, the dryer may automatically cut off the heating unit when the air flow temperature becomes too high to avoid scald the skin and hair. When the air flow temperature drops to a safe range, the heating unit will re-start automatically. This is just for safety, not a malfunction.



Daily Maintenance


Make sure machine power is off when performing any maintanance.

TO CLEAN FILTER SPONGE

Please regularly clean the filter sponge for air entry, at least once per business day. Power off machine. Remove the bolt from the underside of the dryer. Remove the Air Entry Net and Filter Sponge. Clean the Air Entry Net and Filter Sponge by clearing away and hair, fur, and dust, If using water to clean filters be sure to completely dry each component

TO SURFACE CLEAN DRYER:

Use a soft cloth to remove dust and hair from the surface of the dryer. Cleaning solution is NOT reccomended.



Thank you for your purchase of this top-grade professional dryer. This dryer is recommended for use by professional grooming salons for business use.

- High Tech digital control of air speed and temperature
- Larger Anionic motor effectively reduces static
- · Evenly distributed heat
- Drys and fluffs hair
- Perfect for use during styling

Stand or wall-hung options allow for flexible positioning of dryer to allow for hands-free operation.


CAUTION

Dryer must be securely mounted to wall or on stand in accordance with this manual. Follow instructions for safe usage.

- 1. Ensure your voltage and max load current meets product requirements.
- 2. Clear hair/fur on Filter Sponge and Air Entry Net prior to use.
- 3. Turn Air Speed and Temperature switches to low prior to use to avoid sudden strong air flow once dryer is turned on.
- 4. Drver must be positioned out of reach of persons in contact with water.

Technical parameter

Wind Speed	max 20.5m/sec
Air Volume	6.9m3/min
Temperature	MAX: Room Temperature + 60 ℃ (140 F)
Power	110~127V 1700W MAX
Motor Lifetime	≥5000hrs
Max emission sound pressure	<70dB(A)
Require Minimum Load Current (Amperes)	Not lower than 15A



Manufactured for ©Boss Pet Products, Inc., Danvers, MA 01923 Manufactured in CHINA

TP9204 95

NOTICE

REV. 11/22

- 1. This appliance is not intended for use (including maintenance such as cleaning) by persons (including children aged from 8 years and above) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.
- For additional protection, the installation of a Residual Current Device (RCD) having a rated residual operating current notexceeding 30 mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.
- This hairdryer must be fixed out of reach of a person or pets taking a bath or shower.

 The appliance must be fixed so that the hand-held part, when fully extended, is out of reach of a person or pets taking a
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 8. WARNING- Do not use this appliance near water in bathtubs, basins or other vessels containing water!



- 9. Please cear hair/fur on filter sponge before power on every time.
- 10. When the appliance operated, a trained person must watch over the pets to avoid injury to the pets or injury to person by frightened pets.
- 11. Disconnect the appliance from its power source during service and maintence.
- 12. The removal of the plug has to be such that an operator can check from any of the points to which he has access that the plug remains removed.
- 13. This appliance is designed to be used in commercial areas.
- 14. The appliance must have a separate power supply line. Do not use electricity with other high-power equipment.15. Do not insert any metal objects into the gaps of the appliance, nor allow any liquid to drip into it.
- Otherwise, it may cause electric shock personal injury or short-circuit of the appliance.
- 16. Do not cover, wrap, block the air outlet and air inlet to avoid damage to the appliance.
- 17. If there is a malfunction during the use of the appliance, please disconnect the power of the host in time and contact Boss Pet Products Customer Support. DO NOT disassemble the appliance by yourself. Otherwise, Boss Pet Products company and our distributors are
 - NOT responsible for any losses caused by this.
- 18. Please professionally install and use the corresponding stand bracket or wall-mount bracket in strict accordance with this manual.