



**Tools Needed:** Phillips head screwdriver or drill with Phillips head bit

**Unplug the control box from the electric outlet before beginning replacement.**



- 1.** Using a Phillips head screwdriver or drill bit, remove screws holding Control Box Housing Cover in place.



- 2.** Remove the screws holding the old Control Box in place.



- 3.** Unplug the controller and electrical cords from the control box.



- 4.** Loosen screw holding wire retainer in place. Remove screw holding Ground Wire and cords in place.



- 5.** Remove rubber gasket from the Control Box Housing and slide over the electric cord plug. Slide Electric cord plug through hole to inside of housing.



- 6.** Remove old Control Box from housing. Insert New Control Box and slide Electric Cord Plug through the hole.



- 7.** Slide the rubber gasket over the new Electric Cord Plug.



- 8.** Return rubber gasket to control box housing.




- 9.** Secure wires and cord in Retainer and tighten screw. Secure Ground wire to 2nd screw and screw in place on retainer.



**10.** Plug controller and electrical cords into new control box.



**11.** Plug the cords that connect the electrical controls to the new Control Box.  
(I) for the Electric Lift Mechanism, and (II) for the Electric Foot Pedals or Controls.




**12.** Replace the Control Box Housing Cover and secure in place with screws.

### For New Electric System:



**1.** Press the bracket release button in the direction away from the control box.



**2.** Unplug the cords that connect the electrical controls and lift mechanism to the old Control Box.  
**3.** Remove the old Control Box.  
**4.** Mount new control Box on bracket.



**5.** Plug the cords that connect the electrical controls to the new Control Box.  
(I) for the Electric Lift Mechanism, and (II) for the Electric Foot Pedals or Controls.

## LIMITED WARRANTY

This Master Equipment® TP1013 17 Replacement Control Box is warranted against defective material or workmanship for one year from the date of purchase. Any Master Equipment® product that is determined to be defective in material or workmanship during the warranty period will be replaced without cost to the purchaser for parts or labor. Please contact Boss Pet Products Customer Service at 1-800-638-5754 regarding any defective product. Boss Pet Products will not be liable under this warranty for any defect, failure or malfunction of this product caused by normal wear, abuse, misuse, unauthorized adjustments or repairs. Boss Pet Products will not be liable for any incidental or consequential damages of any type. Any implied warranty is limited to the one-year period provided in this express warranty. Some states do not allow limitations on how long an implied warranty lasts or exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. Warranty is void if product has been modified in any manner, repaired by anyone other than Boss Pet Products or has been subject to unreasonable use. Warranty is valid in the United States.

Date Purchase: \_\_\_\_\_



Manufactured for  
© Boss Pet Products, Inc., Danvers, MA 01923  
MADE IN CHINA

TP1013 17 Master Equipment  
Replacement Control Box