




# COLOR EX-PEN ASSEMBLY INSTRUCTIONS



## Instructions for use:

Unfold ex-pen and arrange panels into desired configuration. Open bolt snaps on edge of end panel and securely attach to wire rung of opposite end panel (Figure A).

Push latches down against pen panel to secure.

Optional ground stakes to anchor pen securely to dirt or grass are also available separately.

## Care instructions:

Do not use harsh detergents or abrasives. To clean, use mild soapy water and a sponge or soft cloth to wipe away stains. Rinse and dry thoroughly.

## Note:

We suggest the use of anchoring stakes when used on grass or dirt. For the safety of your pet, we recommend that you remove collars, tags or any other articles from your pet which may potentially snag between wires.